



Elevated Work Platforms

Monitor the location, operating hours, fuel or battery condition and utilisation of elevated work platforms across your fleet.

Monitor machine tilt and stabiliser deployment to provide greater visibility of operating conditions and how equipment is being used.

Use actual operating hours to schedule servicing, identify underutilised equipment and receive alerts when machine conditions require attention.



Connect to the machine CAN bus to access engine, controller and operating data without adding unnecessary sensors.

Use the inbuilt accelerometer to monitor machine tilt and detect movement or impacts.

Digital inputs monitor stabilisers and machine controls.

Receive alerts via SMS and email.

Why Senquip?




Connect to Anything

Interface to any engine, controller, or sensor, no matter the brand, physical interface, or protocol.



Process Everything

Edge process measured data, create custom alerts, and control connected systems.



Send Anywhere

Send data to the Senquip Portal or any other server. No ongoing costs, no lock in contracts.



Trusted Everywhere

Designed for use in harsh industrial, mining, and agricultural environments.




Senquip ORB

For extreme environments where IP ratings are essential and external antennas may be damaged. Typically mounted on poles, walls, and externally on machines



Senquip QUAD

For harsh environments where external antennas are a benefit. Typically found in electrical cabinets, in operator cabs, and mounted externally on machines.



Senquip Portal

The Senquip Portal is a secure cloud solution that offers a no-cost or low-cost device management and data hosting + analytics solution for Senquip devices.



TELEMETRY FOR HARSH ENVIRONMENTS